

MediFurn push through cabinet for 6 StU

Технические характеристики изделия 7504604 | DRS 6StE 1150/900/1800



Показан пример без декоративных элементов, точность технического описания не гарантируется.

Технические характеристики

Мощность: 50 W Входное напряжение: 220 V Номинальный ток: 0,2 A Класс защиты: Class I Частота: 50 Hz Macca: 170 кг Ширина: 1150 мм Глубина: 900 мм Высота: 1800 мм

Pass-through chamber as sluice for temporary storage of supplies between clean and unclean areas as well as for providing sterile supplies and disposing of unclean material on Hupfer 6 STE transport trolleys.

Cabinet made entirely of high-quality stainless steel, robust, self-supporting and hygienic design. Structure closed on all sides, with two double-walled double-wing doors each on the clean and unclean sides. Doors with continuous seals, opening outwards with the doors additionally being lifted on the retracting side by special lifting hinges. The left of each double wing door has an overlapping strip. Mutual locking of both doors through electromagnetically acting door lock, preventing the simultaneous opening of the doors to the clean and unclean sides. Red indicator lights located centrally above the doors indicate open doors at the opposite side respectively; green illuminated push-buttons enable releasing the doors underneath, provided the doors on the opposite side are closed. Tiltable switch box in interior houses electrical control system and emergency stop switch for releasing the doors in an emergency. In case of a power failure, all doors unlock automatically. The underpressure or overpressure created in the cabinet when opening or closing is compensated for by a compensation opening in the top. Interior with docking rail as stop on the clean side, allowing extension and retraction of a Hupfer 6 STE transport trolley exclusively on the unclean side. Two horizontal guide tubes on the long side serve as centring aids in the area of the transport trolley's bumper strip. The wall opening or recess dimensions required for installing a pass-through chamber can be found in the Hupfer installation conditions.

Дата обращения: 17.07.2025, 12:43:04 Значения величин и размеров являются приблизительными, точность технического описания не гарантируется. © Hupfer